

Modifying the MicroRouter 900i for LAN-Dial

Changing the Dial Up Phone Number

Our internet access phone numbers can be retrieved via e-mail at numbers-info@psi.com or via our FaxBack server by dialing 518-283-8860 and choosing option 4. Follow the prompts, select code number 1002, and key in your fax number. **Please be sure to check with your telephone company to insure it is a local call, as long distance charges will apply and be your sole responsibility.**

From the 900i prompt, type en to put the router in enable mode:

```
*900dialup>en
```

Type the password at the prompt.

View the chat script:

```
*900dialup#show chat script
```

```
script:  
send atdt14154424600  
expect CONNECT
```

The phone number this router is dialing is 14154424600.

To edit the script, type edit chat script:

```
*900dialup#edit chat script
```

```
Editing "script" ...  
  
1: send atdt14154424600  
2: expect CONNECT  
End of buffer
```

Then type a, for append:

```
Edit script>a
```

Type in the line with the new phone number:

```
Append>send atdt4424600
```

Type a period on a line by itself to stop the APPEND:

```
Append>.
```

To verify the script while in edit mode, type print 1 10:

```
Edit script>print 1 10
```

Modifying the MicroRouter 900i for LAN-Dial (cont'd)

The 1 10 represents the range of chat script lines to print. It does NOT matter if there are less than ten lines in the chat script.

```
1: send atdt14154424600
2: send atdt4424600
3: expect CONNECT
End of buffer
```

To delete line 1, which contains the wrong phone number, type delete (d) 1:

```
Edit script>d 1
```

NOTE: You may also delete a range of chat script lines (e.g. delete 1 5).

Type exit to exit edit mode.

```
Edit script>exit
```

To save the changes:

```
*900dialup#save
```

Answer yes to restart router.

Forcing Compatible Systems 900i to Dial

Once connected into the 900i, put the router in enable mode by typing:

```
900dialup>en
```

Enter the password: (default is letmein).

To force the router to dial out type sys upline 0, the 0 refers to the WAN port number:

```
900dialup#sys upline 0
```

WAN0: attempting to bring link up

To drop the line, type **sys dropline 0**.