

Setup: RNS NetHopper for LAN-Dial

Instructions for connecting your Rockwell Network Systems NetHopper Router:

Prerequisites: Please run through the following flowchart to connect your equipment prior to scheduling your initial appointment with our Installations Group.

- Local Area Network (LAN) already setup
- TCP/IP configured on the individual workstations
- Analog telephone line installed by your telephone company

Your router has been shipped to you preconfigured. Please check the configuration print out to verify that the dial-up phone number the number you want to be dialing into. Also, when the connection is up and running, don't forget to change the router password.

