

## Setup: Netopia R3100 Router for LAN-ISDN

Instructions for connecting your Netopia Router:

**Prerequisites:** Please run through the following flowchart to connect your equipment prior to scheduling your initial appointment with our Installations Group.

- Local Area Network (LAN) already setup
- TCP/IP configured on the individual workstations
- ISDN line installed by your telephone company
- Switch Type: **National ISDN-1**, 5ESS pt to pt, 5ESS multipoint, DMS100
- SPID Numbers: \_\_\_\_\_
- Directory ID: 7 digits of the SPID numbers excluding the area code.

Your router has been shipped to you preconfigured. If you provided us with the Switch Type and SPID numbers prior to shipment, the router's configuration should be complete. If we did not receive this information in time you will need to telnet into the router to add these parameters to the router's configuration. Please check the configuration print out to verify that the dial-up phone number is the number you want to be dialing into. Also, when the connection is up and running, don't forget to change the router password.

